

Useful Bar Codes

Set Defaults



Return to Factory Defaults

Add a Tab Key

To add a Tab key after scanned data, scan the bar code below.



Tab Key

Add an Enter Key

To add an Enter key after scanned data, scan the bar code below.



USB Caps Lock Override



USB-Override Caps Lock Key
(Enable)



*USB-Do Not Override Caps Lock Key
(Disable)