

Data Matrix

Parameter # 292

To enable or disable Data Matrix, scan the appropriate bar code below.



*Enable Data Matrix
(1)



Disable Data Matrix
(0)

Data Matrix Inverse

Parameter # 588

This parameter sets the Data Matrix inverse decoder setting. Options are:

- **Regular Only** - the digital scanner decodes regular Data Matrix bar codes only.
- **Inverse Only** - the digital scanner decodes inverse Data Matrix bar codes only.
- **Inverse Autodetect** - the digital scanner decodes both regular and inverse Data Matrix bar codes.*



*Regular
(0)



Inverse Only
(1)



Inverse Autodetect
(2)

LEER ESTE CÓDIGO
PARA QUE DETECTE
LAS MICRO ID



NOTE For HC configurations, the default is **Inverse Autodetect**.